

For The Commodore 64 and 264
Personal Computers

With Checkholder™

Silent Butler™

... Your Trusted Servant

Commodore and Silent Butler Software Presents
The Personal Management Series

Silent Butler™

... Your Trusted Servant

With your permission...

- I am ready to use; NO setup; (NO manual or menus to learn), simply put the disks in your computer and CALL ME.
- I am "Crash Resistant"; Even after a power failure I will return to where I was working for you.
- I will manage your personal finances and records, (including multiple Savings & Checking Accounts) and your other essential bill paying needs, eliminating duplication of effort.
- I will even balance your Checkbook and pay your bills.
- I will also remind you of Birthdays, Anniversaries, Appointments, and other important dates.
- I will provide you a tax summary ready for you to fill-out your IRS FORM 1040 at tax time.
- And more...

Your **SILENT BUTLER™**

Designed to be used every few days so that record-keeping and financial management becomes a simple task and not a drudgery.

No Computer Experience Necessary

What you will need...

Commodore 64 or 264 Personal Computers with:

- One 1541 Disk Drive
- Color or Monochrome Display or TV
- 1525, 1526, or MPS 801 Printer (optional)

Already Included...

CHECKHOLDER™

Allow me to do the rest...

Your **SILENT BUTLER™**

My CHECKHOLDER™ will allow me to actually pay your bills right on your normal personal checks, taken right out of your checkbook.


SILENT BUTLER™ Checkholder™
When you instruct me to pay bills, might I request you to do the following so that I may write the appropriate checks...
[A] Place the requested number of checks from your checkbook (in order of the check numbers) into the CHECKHOLDER™. The face of each check will be visible, including the corners, except under the holding straps and along part of the top edge of the check.
[B] Slide the CHECKHOLDER™ into your computer printer the same as you would standard paper. Roughly align the Matchmark on the CHECKHOLDER™ with the Matchmark on the top of the sprocket unit. Align the Print Head mark on the CHECKHOLDER™ with the print head when it is in the home position, if necessary the first time you use the CHECKHOLDER™. If your printer has a release lever and paper scale, please push the paper scale back into position against the CHECKHOLDER™, but leave the release lever unlocked.
[C] Turn the manual feed knob to align the Matchmarks, if necessary
[D] Ensure the printer is "ON" and the "ON LINE" light is illuminated.
[E] Now, please instruct me to write your checks.
[F] When the check printing is finished, use the manual feed knob or the line feed button to advance the remainder of the CHECKHOLDER™ from the printer.
Thank you for assisting me...
Your SILENT BUTLER™
Matchmark
Print Head
JAMES C. MORRISON
1765 SHERIDAN DRIVE
YOUR CITY, U.S.A. 12345
DELUXE CHECK PRINTERS, INC.
SAMPLE-VOID

commodore COMPUTERS

scanned by: www.commodore.international